

# 102. Recommended spare parts: DWK, DPK

## 50/60 Hz

### Customer Information

Project title:	Customer name:
Reference number:	Customer number:
Customer contact:	Customer phone number: (____)
	Fax number: (____)

<b>Pump information</b>	<b>Quotation made by</b>
-------------------------	--------------------------

Type		Prod. No.	
P.c.	ø mm	No.	
▽	T °C	P	Insul. class:
Model	Pol	Hz	V
P <sub>1</sub> /P <sub>2</sub>	kW	I <sub>N</sub>	A <sub>start</sub> A <sub>N</sub> /min
Cosφ		Weight	kg
Ex			

**GRUNDFOS**  
CH-6105 Schachen

Company name: \_\_\_\_\_

Prepared by: (\_\_\_\_) \_\_\_\_\_

Phone number: (\_\_\_\_) \_\_\_\_\_

Fax number: (\_\_\_\_) \_\_\_\_\_

Date: \_\_\_\_\_

Quote number: \_\_\_\_\_

### Recommended spare parts

Kit - Spare - Bulk	Recommended service parts						Product number
	1 pump		2 to 3 pumps		4 to 7 pumps		
	2 years	5 years	2 years	5 years	2 years	5 years	
	units per pump	units per pump	units per pump	units per pump	units per pump	units per pump	
Kit, Shaft seal	1	2	2	3	4	8	
Kit, O-ring	1	2	2	3	4	8	
Kit, Impeller	0	1	0	2	0	4	
Kit, Bearing	0	1	0	2	0	4	
Oil <sup>1)</sup>	1	2	2	3	4	8	

1) See service instruction for amount and type.

Above recommendations are based on:

Agitators running in normal operation should be checked every 3000 operating hours or at least once a year.

If the stirred liquid is very muddy or sandy, check the pump at shorter intervals.

96488862 06.2022

**GRUNDFOS Holding A/S**  
Poul Due Jensens Vej 7  
DK-8850 Bjerringbro  
Tel: +45 87 50 14 00  
[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** 